

Car Seat Demo Bench



CPS Resources, LLC

STANDARD ONE YEAR MANUFACTURER WARRANTY

The manufacturer warrants this product to be free from defects in workmanship and materials, under normal residential use and conditions, for a period of one (1) year from the original invoice date.

The limited warranty extends for one year from the date of initial purchase, covers only to the initial purchaser located within the U.S. and is not transferable. This limited warranty does not cover damage or claims to any product or component CPS Resources, LLC determines to have been damaged by or subjected to:

- Inadequate alteration, modification, misuse, theft, vandalism, or failure to maintain.
- Acts of God, water, excessive heat, or moisture damage.
- Normal wear and tear, product deterioration, scratches or defects in product finishes, damage due to shipping, or other negligent, intentional, or unintentional damage.

Shipping and handling fees are to be paid for by the customer. The manufacturer agrees, at its option during the warranty period, to repair and defect in material or workmanship or to furnish a repaired or refurbished product of equal value in exchange without charge (except for a fee for shipping, handling, packing, return postage, and insurance which will be incurred by the customer). Such repair or replacement is subject to verification of the defect or malfunction and proof of purchase as confirmed by showing Proof of purchase on original dated sales receipt.

MATERIALS

Fabric – The manufacturer warrants the upholstery fabric used on your demo seat against seam failure, fabric separation and nap loss for one year. The manufacturer cannot cover pilling of fabric, normal wear due to proper use, transportation storage which is a result of normal wear or overexposure to sunlight and extreme weather conditions including excessive heat, cold and humidity.

Leather/Vinyl – The manufacturer warrants leather upholstery against seam failure and material defects for one year.

Plastics/Hardware/Seat belt components – The manufacturer warrants the plastics, hardware and seat belt components used on your demo seat against failure of components which is a result of normal wear, overexposure to sunlight and extreme weather conditions including excessive heat, cold and humidity.

WARRANTY LIMITATIONS

This warranty does not include:

- Any condition resulting from other than ordinary residential wear or any use for which the product was not intended, such as use in rental or contract trade or commercial use.
- Any condition resulting from incorrect or inadequate maintenance or care.
- Damage resulting from misuse, abuse, negligence, accidents, or shipping damage.
- Dissatisfaction due to buyer's remorse.
- Normal wear and tear.
- Damages incurred during transportation.
- Damages incurred during assembly or maintenance.
- Any used, previously displayed items.

Car Seat Demo Bench

CPS Resources, LLC makes no express warranty or condition whether written or oral and the company expressly disclaims all warranties and conditions not stated in this limited warranty. To the extent allowed by the local law of jurisdictions outside the United States, the Company disclaims all implied warranties or conditions, including any implied warranties of merchantability and fitness for a particular purpose. For all transactions occurring in the United States, any implied warranty of condition of merchantability, satisfactory quality, or fitness for a particular purpose is limited to the duration of the express warranty set forth above. Some states or countries do not allow a limitation on how long an implied warranty lasts or the exclusion of limitation of incidental or consequential damages for consumer products. In such states or countries, some exclusions or limitations of this limited warranty may not apply to the Purchaser. For consumer transaction, the limited warranty terms contained in this statement, except to the extent lawfully permitted, do not exclude, restrict, or modify but are in addition to the mandatory statutory rights applicable to the sale of this Product to the Purchaser.

CLAIM PROCEDURES

- Claims for defective merchandise must be made within ONE year from the invoice date.
- Claims for missing parts must be made within thirty calendar days after the merchandise is received.
- Any claim for defective merchandise returns must be packed in original packaging.
- We reserve the right to specify that items be returned to the original warehouse for inspection or be inspected by our representative in the field.
- Pictures are required to claim defective merchandise, along with a copy of the original invoice.
- If the claim is justified, the item(s) or part(s) will be repaired or replaced, or a credit will be issued. It is our policy to replace parts whenever possible.

This warranty gives you specific legal rights. You may have other rights, which vary from state to state.

Car Seat Demo Bench



CPS Resources, LLC

Use Instructions:

Thank you for your recent purchase of your new demo bench. The Tech Trainer/Parent Educator demo bench is for educational purposes only and is designed to help demonstrate the proper use and installation of car seats, booster seats and seat belts.

Follow these simple instructions to learn how to safely transport and use your new teaching tool.

Moving the demo bench:

- Unlock all four wheels by turning the metal plate to the unlock position.
- Raise the seat back to its full upright and locked position.
- Stand behind the seat back and place both hands on the top edge of the seat, near the head restraint.
- Buckle and secure the lap belt to avoid a trip hazard. Never allow the latch plate and/or webbing to drag on the ground. This will cause damage to the belt and poses a trip hazard.
- Slowly push the demo bench forward. Do not roll over uneven or rough surfaces. Doing so may damage the casters.
- Never pull the seat. Doing so may result in the demo bench tipping over and causing bodily injury and/or damage to the demo seat or other property.
- Do not leave unattended on uneven or sloped surfaces.
- **NEVER allow anyone to sit on, stand on or otherwise lean on the seat or any components while it is being moved. This can result in significant injury and damage to your demo bench which will void the warranty.**

Transporting, loading, and unloading the demo bench

Loading

- Lock the wheels.
- If equipped, fold your head restraints down by pulling the strap on the side of the seat, just below the head restraint.
- Gently lower the seat back by pulling up on the lever on the side of the demo seat. Avoid all pinch points.
- With a partner, **always** use proper team lifting technique to lift your demo bench, Stand on either side of the folded demo seat and lift from the bottom of the platform. NEVER attempt to load or unload the demo bench alone. Doing so may cause injury to you and/or your vehicle.
- Take care not to bump into the retractors. Doing so may cause the retractor to malfunction.
- Carefully set the folded demo seat into the cargo area of the vehicle. Properly secure the demo seat to avoid the risk of injury to you or your passengers.

Unloading

- With a partner, **always** use proper team lifting technique to lift your demo bench, Stand on either side of the folded demo seat and lift from the bottom of the platform. NEVER attempt to load or unload the demo bench alone. Doing so may cause injury to you and/or your vehicle.
- Take care not to bump into the retractors. Doing so may cause the retractor to malfunction.
- Carefully set the folded demo seat on a level, smooth surface.
- While standing in front of the seat, place your knee or hand on the seat and raise the seat back to its full upright and locked position.
- Unlock all four wheels by turning the metal plate to the unlock position.

Car Seat Demo Bench

Note: CPS Resources, LLC. Is not responsible for any damage to the vehicle or injury to any passengers in the vehicle.

Use in the classroom:

A variety of seat belt systems and LATCH are available to demonstrate the proper use and installation of car seats, booster seats and seat belts. Follow these simple steps to ensure your demo seat functions properly.

- Always ensure all four wheels are in the locked position by turning the metal locking mechanism into the locked position. Do not leave unattended on uneven or sloped surfaces.
- Raise the seat back to its full upright and locked position avoiding all pinch points.
- Do not exceed 200lbs. weight limit on the demo bench.
- Do not allow multiple people to sit on the demo bench at one time.
- Avoid excessive force on any part of the demo bench. Doing so may cause damage and will void the warranty.
- NEVER allow anyone to sit on the seat while it is being moved. This can result in serious injury and damage to your demo bench which will void the warranty.

Latchplates

Each latchplate will lock into the buckle on the side of the seat. If you purchased the Tech Trainer, slide the unused latchplates on the shoulder belt out of the way to demonstrate how to properly install a car seat or booster seat. The seat belt contains the following latchplates:

- Sliding
- Dynamic/cinching
- Locking

LATCH

The lower anchors and top tether is used to demonstrate the proper use of the LATCH system. The top tether can be routed under or over the head restraint.

Retractors

Each demo seat comes equipped with a three-point belt system with a switchable retractor and a manually adjustable lap belt. The Tech Trainer model also comes equipped with an ELR lap belt.